

Elite SCREENS

Portable Floor Pull-Up Screen

Elite ez Cinema Plus Series

**FOR MODELS: F68XWS1 / F60XWV1 / F84XWV1 / F74XCH1 /
F84XCH1**

USER'S GUIDE



Matte White

Precautions:



Warning! Screen damage can result from operational errors if the enclosed precautions are not followed.



In accordance with practicing home fire safety and avoiding screen damage, do not place the screen near or beside a fireplace or high temperature objects such as a gas stove, BBQ or heater.



Place the screen beyond the reach of children.




Fig. 1




Fig. 2




Fig. 3

****Note: The Flex Bar is a feature designed to evenly distribute the tension of the screen out to the sides. The Flex Bar is designed to “bow” out from the Top Support Bar. It may bow out a few inches depending on the size of the screen. (Fig.3)***


Operational Instructions:

Installation

The screen should be installed in an area free of very strong wind and away from any fire activity such as a heater, BBQ grill or fireworks display.

1. Extend base feet:

Locate the base feet on the bottom of the box at each end and rotate them until they form right angles.




2. Open the box cover:

Unlatch the buckles at both ends of the box and open the box cover.



3. Pulling up the screen:

Carefully lift the screen by its handle and stop at the desired height position. The screen's "scissor back" spring configuration will support it.




Note: The screen will only stop shortly after the bottom black rise has been exposed.

Putting screen away


1. Retract the screen into case:

Press the screen's handle slowly in a downward motion and allow the screen to retract back gently into the housing.




2. Closing it up:

Snap the buckles into place at both ends and verify that the screen's box is closed securely.




3. Draw the base feet back:

Slightly lift one end of the box at a time and rotate the two feet on the bottom of the box until they are in parallel alignment with the box.



4. Storing the screen:

The recommended place for storage would be a corner spot or in a closet, but the ultimate choice is up to you.



The following points should be noted to assure the sound performance of the screen.

1. Never use your hand to touch the screen surface.
2. Never scrabble on the screen.
3. Don't touch the screen with hard or sharp objects.
4. Please use clean cotton cloth or soft dust brush to remove dust particles from the screen.

Warranty Policy - Manual, Tripod, Pull-up Floor, and Fixed Frame Screens

- Two (2) year warranty parts and labor from purchase date as follows (except for refurbished units as specified below):
- **Refurbished units** carry a **90-day** parts and labor warranty.
- **Demo units or open box items** are **AS IS** items and do not carry a warranty.
- Each party will be responsible for one way shipping during the warranty period.
- **DOA (Defective On Arrival): Must be reported within 7 business days of receipt.** A RMA (Return Merchandise Authorization) number must be issued in order to process a replacement. Elite Screens will replace the DOA (Defective On Arrival) unit with a brand new replacement *(see exceptions below) after the DOA unit is received and/or confirmed defective. Once the product is received, Elite Screens will send out a new *unit to the customer by ground service (subject to inventory availability). Should a problem be reported after the 7-day grace period, the item must be shipped to us for warranty repair.
- **Missing Parts** must be reported within the 7-day (DOA) grace period. If reported after 7 days, customer will be only be responsible for shipping and handling fees. If reported after 30 days of receipt, customer is responsible for cost of the parts and shipping & handling fees.

TWO WAY TO REGISTER YOUR WARRANTY WITH ELITE SCREENS INC.

A. On Line (Faster and Easier) www.elitescreens.com/register.html

B. Fill out & Fax to (562) 483-8498, Attn: Customer Service Dept.

*Your Name: _____

Address: _____

City/State/Zip _____

*Email Address: _____

*Phone: _____

*Screen Model: _____

*Serial Number: _____

*Date of Purchase: _____

*Dealer / Reseller Purchased from (name of the reseller): _____

What is your Projector Model : _____

Application: Home Education Corporation Government
 Others

How would you rate this screen? Excellent Good Ok Improvement needed

Comments:

Contact info:

If you have pictures of your screen you'd like to share with us, please email your pictures to eliteinfo@elitescreens.com or call us at 877-511-1211

*Elite*SCREENS

www.elitescreens.com

For any technical inquiries,

techsupport@elitescreens.com