FOLD MARK

FOLD MARK

**(** 

Juice Booster Instructions

# Fruits and Vegetables:

The Juice Booster is ideal for apple juice, you can put whole, unpeeled apples down the 65mm chute and it will juice them for you. Below are some tips on dealing with other foods:

Carrots	Juice these whole, why not use the juice and pulp for a soup?
Oranges	Peel these first, then put them down the chute
Grapefruit	Peel these first, then put them down the chute
Pears	Juice these whole
Grapes	On the vine
Strawberries	Larger ones are best, smaller may not juice efficiently
Lemons	Peel these first, a bit tricky but worth the wait, why not
	make your own lemonade?
Pineapple	Cut into strips after removing the skin
Blueberries/	The smaller they are the less efficient the juicer becomes
Cranberries	
Kiwis	Peel them first
Mangoes	Peel them first

Juice is sent to the Juice Collection Vessel (1 litre) and residue such as the skin from an apple is sent to the Residue Collector.

For ease of cleaning it is suggested you line the Residue Collector with a plastic bag and just take this bag out when it becomes full.

Juice Booster Instructions


## Warnings

- The Juice Booster should always be used on a flat, dry surface.
- The Juice Booster will only work when the two safety locking arms are in place.
- The Juice Booster has a protective device that will automatically switch the unit off if overheating occurs, the unit will work again when the motor cools (15 minutes).
- Do not use continuously for more then two minutes at a time; switch off for one minute in between each two minute use.
- If power cord is damaged it must be replaced and only by a suitably qualified electrician.
- Keep out of reach of children. This is not a toy.
- Store in a dry and ventilated area.
- Do not place on or near any hot surface.
- Do not drop the unit; this may cause dysfunction.
- Do not let the cord touch any hot surfaces or become knotted.
- Do not use with an extension cord or multi plug.
- Only use as described in these instructions.



# **Juice**Booster

Enjoy the goodness of pure, fresh fruit juice everyday



**INSTRUCTIONS** 



FOLD MARK FOLD MARK

FOLD MARK FOLD MARK




Juice Booster Instructions

### First use and assembly

- 1. Intake part
- 2. Clear cover
- 3. Blade system (push down firmly to fix in place)
- 4. Residue channel
- **5.** Locking arms
- 6. Residue collector
- 7. Speed/Off Switch
- 8. Base part
- 9. Juice collection vessel

When you first use the product you should assemble as in the diagram, it is very important to ensure that the two locking arms (5) are clipped into place, holding the clear cover (2) and therefore also the blade system and residue channel in place.

The Juice Booster has a massive 65mm diameter chute to juice apples...whole!



Juice Booster Instructions

#### Use

- Assemble all the parts as in the diagram, then plug in the unit (ensuring unit is switched OFF) and switch on at the wall.
- You should place the fruit or vegetable in the chute and place the intake part (1) in the chute (there are guides inside the chute to ensure the intake part stays straight).
- With your hand holding the intake part down, turn the switch to speed 1
   or 2. 1 is for softer foods and 2 is for harder foods.
- Press down firmly on the intake part, the slower this part goes down, the more juice you will get. Always use the intake part and never use hands to push down food items.
- When the whole of the food is juiced, turn the unit off. If juicing lots of fruits, do not leave switched on continuously for more than two minutes.
   Leave to cool for at least one minute before using again.

# Cleaning the Juice Booster

The unit must be switched off and unplugged before cleaning.

To clean the unit, disassemble. You may rinse parts 1, 2, 4, 6 and 9 with warm soapy water. Part 3, the Blade System, should be cleaned carefully after use again with warm soapy water.

The Base Part (8) should be cleaned with a damp cloth and none of the parts should be reassembled, plugged in or turned on until thoroughly dry.

#### Guarantee:

This product is unconditionally guaranteed for one year against all defects of workmanship and materials.

This guarantee does not effect your statutory rights.

If this product proves unsatisfactory please phone our dedicated Customer Service team on 020 7691 3888 or write to John Mills Ltd.,

JML House, Regis Road, London NW5 3EG.



Just Eat More (fruit & veg)

The Juice Booster is a fun and easy way to help you get your recommended five portions of fruit and vegetables everyday.

See www.5aday.nhs.uk/ for more details.



John Mills Limited JML House Regis Road London NW5 3EG Tel:020 7691 3800 Fax: 020 7691 3888 info@johnmillsltd.co.uk www.jmldirect.com



FOLD MARK FOLD MARK