

PARTS & ASSEMBLY SHEET

Fixture Name: Empyreal 1220-SF RT

This fixture assembled PO: D	Date:
------------------------------	-------

Notice: Please review the parts listing and check for all parts before assembling the fixture. If any parts are missing or damaged, please note on this sheet and contact the place of purchase to arrange for replacement parts.

Company Name:		Co. Account	#:
to be filled out by retailer			
Wire connectors		Тор Іоор	
3ea P3 Orange		1ea 3/8"IP*H80mm	
Junction Box Screw		Spring Washer	
2ea #8-32N*H25mm		1ea Ф15*H3mm	
Canopy Loop with Collar		Nipple	
lea @3/8 x 42.4mm x 3	5mm loop	1ea @3/8 x 45mm	
Hex Nut		Deco Nut (Round)	
4ea @3/8 x 3mm		2 ea 5/32"xH9mm	custos — — escepci
Mounting Screw		Screw	
2ea 5/32"*H32mm		2ea 5/32"*H6mm	
Hex Nut		Rubber Washer	
4ea @5/32"*H3.5mm		1 ea Ø53*H2mm	
Finial		Metal Washer	
1ea 3/8"*10MM		1ea Ø55*H0.8mm	
		Quantity	
		Quantity	
ed, broken glass, be	nt, bad finish)	-	
	to be filled out by re Wire connectors 3ea P3 Orange Junction Box Screw 2ea #8-32N*H25mm Canopy Loop with Collar 1ea @3/8 x 42.4mm x Hex Nut 4ea @3/8 x 3mm Mounting Screw 2ea 5/32"*H32mm Hex Nut 4ea @5/32"*H3.5mm Finial 1ea 3/8"*10MM	to be filled out by retailer Wire connectors 3ea P3 Orange Junction Box Screw 2ea #8-32N*H25mm Canopy Loop with Collar 1ea @3/8 x 42.4mm x 5mm loop Hex Nut 4ea @3/8 x 3mm Mounting Screw 2ea 5/32"*H32mm Hex Nut 4ea @5/32"*H3.5mm	Top loop 3ea P3 Orange Junction Box Screw 2ea #8-32N*H25mm Canopy Loop with Collar 1ea @3/8 x 42.4mm x 5mm loop Hex Nut 4ea @3/8 x 3mm Mounting Screw 2ea 5/32"*H32mm Pec 5/32"*H6mm Rubber Washer 1ea @5/32"*H6mm Rubber Washer 1ea @5/32"*H6mm Rubber Washer 1ea @5/32"*H6mm Rubber Washer 1ea @5/32"*H0.8mm Quantity Quantity

FIXTURE ASSEMBLY INSTRUCTIONS

Read and review installation instruction sheet before assembling the fixture.

For Semi-Flush version:

1. Install the fixture Frame to ceiling then continue with Shade installation on Fig 1, Step 9

NOTE: INSTALL THE SHADE ASSEMBLY AFTER THE FIXTURE IS HUNG.

For Customer Service, contact the place of purchase to arrange for replacement parts.


PARTS & ASSEMBLY SHEET

Fixture Name: Empyreal 1220-SF RT

ASSEMBLING THE FIXTURE as Chain hung (Fig.2)

- 1. Remove the Circular strap from top of Fixture and replace the long mounting screws with two short screws(O) to hold the Deco nuts (F) in place on the fixture Top cap (E).
- 2. Feed the fixture wires through the Top loop (P) and pull the wires until taut. Then screw the Top Loop (P) to the coupler in Top Cap until tight.
- 3. By measuring determine correct number of links needed for proper hanging height. Use a pair of pliers to open one link of the Chain (K) then remove the excess Chain (K) and discard it.
- 4. Use one chain connector (L) to attach one end of the chain to the Top loop (J) and close the chain connector.
- 5. Feed the fixture wires through the Chain (every three links) and pull the wires until taut.
- 6. Slip Canopy loop collar (H) over the chain, then do the same with the canopy (G).
- 7. When ready to complete the installation Use the other chain connector and attach the other end of the chain to the canopy loop (F) and close the chain connector.
- 8. Make sure the weight of the chandelier will be supported by the chain-not the electrical wire.
- * You may now install the fixture. Note: Complete these remaining steps after the fixture is hung.
- 9. Thread Nipple (H) into Socket Assembly (G), and lock into position by tightening Hex Nut.
- 10. Install light bulbs in accordance with the fixture's specifications.
- 11. Slide Shade (I) over Nipple (H) so the Nipple (H) protrudes through bottom of Shade (I), slide Rubber Washer (J), Metal Washer (K) over Nipple (H) and secure with Hex Nut (L)
- 12. Slide Bottom Cap (M) over the Nipple (H), screw the Finial (N) onto the Nipple (H) until tight.

NOTE: DO NOT EXCEED THE MAXIMUM WATTAGE



For Customer Service, contact the place of purchase to arrange for replacement parts.



INSTALLATION INSTRUCTIONS

Fixture Name: Empyreal 1220-SF RT

For Pendant Light Fixture


WARNING! SHUT OFF POWER AT FUSE OR CIRCUIT BREAKER.


HANGING THE FIXTURE as Pendant (Fig.1)

- 1. Carefully remove the new fixture from the carton and the yellow bag that holds all parts. Check that all parts are included as shown in the illustration and parts list.
- 2. Shut off the power at the circuit breaker and remove old fixture from ceiling, including the old mounting strap.
- 3. Thread Nipple (C) into Canopy Loop (F) until snug.
- 4. Thread other end of the Nipple (C) with Canopy Loop attached into Mounting Strap (D).
- 5. Place Lock Washer (B) over end of Nipple (C) protruding through Mounting Strap (D) and thread Hex Nuts (A) onto Nipple until tight.
- 6. Take this mounting strap assembly and mount to ceiling junction box with junction box Screws (E). Tighten screw securely with screw driver.
- 7. Unscrew the Canopy loop collar (H) from the Canopy loop. Take the canopy and pass over the Canopy loop. approximatly one half of the canopy loop exterior threads should be exposed. Adjust until desired height is reached. *the Canopy loop collar should fit snugly on the Canopy loop after the canopy is installed. Remove Canopy and Canopy lock collar.
- 8. Assemble the fixture and have an assistant or secure support hold the weight of the fixture while you complete the wiring connections.
- 9. Thread the fixture wires and ground wire of the assembled fixture through the canopy loop and nipple and into the outlet box. **CONNECTING THE WIRES** (Fig 2)
- 10. Attach the power supply wires to the fixture lead wires by connecting BLACK to BLACK (or SMOOTH) and WHITE to WHITE (or RIBBED).
- 11. Attach the GROUND wire(GREEN or COPPER) from the Junction Box and the fixture Ground wire to the green Ground Screw on the Mounting Bracket (D) or connect both wires together using the correct size of wire connectors.

NOTE: Twist the wires together in the same direction you twist the wire connector onto the wires.

- 12. Tuck these wire connections neatly into the Junction Box.
- 13. Raise Canopy (G) to the ceiling and secure in place by tightening the Canopy loop collar (H) into the Canopy Loop (F)
- 14. Install the light bulbs and glass shade as per the fixture assembly sheet.





YOUR INSTALLATION IS NOW COMPLETE.
RETURN POWER TO THE JUNCTION BOX AND
TEST THE FIXTURE.

For Customer Service, contact the place of purchase to arrange for replacement parts.



INSTALLATION INSTRUCTIONS

Fixture Name: Empyreal 1220-SF RT

For Semi-Flush Fixture

WARNING! SHUT OFF POWER AT FUSE OR CIRCUIT BREAKER.

HANGING THE FIXTURE as Semi-Flush (Fig 1)

- 1. Carefully remove the new fixture from the carton and the yellow bag that holes all your parts. Check that all parts are included as shown in the illustration and parts list.
- 2. Shut off power at the circuit breaker and remove the old fixture from wall, including the old mounting strap.
- 3. The Mounting Strap (B) contains several pairs of threaded holes, find the pair of holes that match the holes spacing in your fixture Canopy (E) and thread the two Mounting Screws
- (A) into the Mounting Strap (B), secure with Hex nuts (D).
- 4. Place the Mounting Strap (B) over the Junction Box so the Mounting Screws (A) are vertical or horizontal, as required by fixture type.
- 5. Attach the Mounting Strap (B) to the Junction Box by using the two mounting screws (C). Tighten the screws securely.

CONNECTING THE WIRES (Fig 2)

- 6. Attach the power supply wires to the fixture lead wires by connecting BLACK to BLACK (or SMOOTH) and WHITE to WHITE (or RIBBED).
- 7. Attached the GROUND wire (GREEN or COPPER) from the Junction Box and the fixture Ground wire to the green Ground Screw on the Mounting Strap (B) or connect both wires together using the correct size of wire connectors

NOTE: Twist the wires together in the same direction you twist the wire connector onto the wires.

8. Tuck these wire connections neatly into the Junction Box.

FINISHING THE INSTALLATION (Fig 3)

- 9. Place the fixture Canopy (E) over the Mounting Strap (B) and over the Mounting screws (A), so they protrudes through the holes in the Canopy (E).
- 10. Thread the Deco Nut (F) onto the Mounting screws (A) and continue turning until the Canopy (E) is snug against the wall.
- 11. Install shade and light bulbs as per the fixture assembly instructions

(DO NOT EXCEED THE MAXIMUM WATTAGE RATING)

