

ASSEMBLY AND INSTALLATION INSTRUCTIONS

LK34215-C

WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements.
2. The combined weight of your ceiling fan and light kit cannot exceed 35 pounds unless additional support is provided for the fan.

WARNING:

As per EPACK 2005 requirements, this fan light has a built-in current limiting device to conserve energy. The fan light will not operate if the combined wattage of the installed bulbs exceeds 190 Watts. If the fan light shuts off shortly after being switched on, it may be due to excessive current demand. You should replace the light bulbs with lower wattage bulbs.

1. Remove the switch box cover from the switch box of the fan by loosening the three switch box screws.
2. Unscrew the center plug from the switch box cover and discard it.
3. Thread the wires through the switch box cover, washer and hex nut, then attach the stem of the light kit to the hole of the switch box cover and secure it with the washer and hex nut.
4. Pull out the wires from the switch box. Make wire connections using the wire nuts:
 - The black wire from the light kit to the black or blue wire from the fan.
 - The white wire from the light kit to the white wire from the fan.
 - Carefully put the wires back into the switch box.
5. Restore the switch box cover back to the switch box using the three switch box screws.
6. Install bulbs (included). See relamping label at socket area or packaging for maximum allowed wattage.
7. Thread the pull chain through the glass shade, rubber pad, metal pad and hex nut, and secure them with the hex nut.
8. Thread the pull chain through the cover and finial, and secure them with the finial.
9. Turn on the power at the main fuse or circuit breaker box. (You can control the lights with the pull chain.)

